


TEK250 CONNECTION DIAGRAM



NOTE: Earth connections not shown.

THIS DIAGRAM IS FOR INFORMATION PURPOSE ONLY.
ALL RESPONSIBILITY IS THAT OF THE INSTALLER.
ANY WORK SHOULD BE CARRIED OUT BY A QUALIFIED
INSTALLER ONLY.


TEKELEK AUSTRALIA
SOUTH AUSTRALIA

**GENERIC
CONNECTION DIAGRAM**

TITLE
TEK200 SERIES
CONNECTION DIAGRAM

PAGE
1 OF 4

TEK248 CONNECTION DIAGRAM



NOTE: Earth connections not shown.

THIS DIAGRAM IS FOR INFORMATION PURPOSE ONLY.
 ALL RESPONSIBILITY IS THAT OF THE INSTALLER.
 ANY WORK SHOULD BE CARRIED OUT BY A QUALIFIED
 INSTALLER ONLY.

TEKELEK AUSTRALIA
 SOUTH AUSTRALIA


GENERIC
CONNECTION DIAGRAM

TITLE TEK200 SERIES CONNECTION DIAGRAM	PAGE 2 OF 4
--	----------------


FAN MOTOR CONNECTION OPTIONS

DUAL WINDING (RUN/START) SPEED CONTROL


1. MOTOR with SEPARATE CAPACITOR



2. MOTOR with INTEGRAL CAPACITOR




3. 2-WIRE MOTOR with INTEGRAL CAPACITOR




SINGLE WINDING (RUN ONLY) SPEED CONTROL

1. MOTOR with SEPARATE CAPACITOR



2. MOTOR with INTEGRAL CAPACITOR




THIS DIAGRAM IS FOR INFORMATION PURPOSE ONLY.
ALL RESPONSIBILITY IS THAT OF THE INSTALLER.
ANY WORK SHOULD BE CARRIED OUT BY A QUALIFIED
INSTALLER ONLY.

TEKELEK AUSTRALIA
SOUTH AUSTRALIA


GENERIC
CONNECTION DIAGRAM

PUMP MOTOR CONNECTION OPTIONS

1. SHADED POLE or 2-WIRE PUMP MOTORS



2. INDUCTION MOTOR with SEPARATE CAPACITOR



START CAPACITOR LOCATED
WITHIN TEK248 ENCLOSURE

THIS DIAGRAM IS FOR INFORMATION PURPOSE ONLY.
ALL RESPONSIBILITY IS THAT OF THE INSTALLER.
ANY WORK SHOULD BE CARRIED OUT BY A QUALIFIED
INSTALLER ONLY.

TEKELEK AUSTRALIA
SOUTH AUSTRALIA

GENERIC
CONNECTION DIAGRAM

TITLE	PAGE
TEK200 SERIES	4 OF 4
CONNECTION DIAGRAM	